

FOAM GUN PRO TIPS:

1. Lubricate the foam gun by applying petroleum jelly to tip, threaded portion of adapter basket and ball valve.
2. Set the can of foam upright and hold collar steady while you screw gun onto can. **DO NOT** shake can until after it is attached to gun.
3. After the gun is seated on can, shake system to agitate mixture.
4. Shake system every few minutes.
5. When finished, close the bead size controller on back of tool.
6. Always have a can of foam mounted on gun (even if can is empty).
7. Can of foam may be left mounted to gun for 30 days of down time.
8. Always purge air bubble from tool after mounting new can.
9. Clean tool periodically (after every 12–24 cans or as needed). Rub end of tool on soft wood to clean cured foam from it.
10. **NEVER** leave a can of cleaner mounted on gun for more than 15 minutes.
11. Store can with gun attached upright. **DO NOT** store on its side.



USING YOUR NEW FOAM GUN:

1. APPLYING THE FOAM

- Shake the can for 1 minute.
- Purge air from gun by spraying foam for 5–10 seconds before applying.
- Control the size of foam bead (from 1/4" to 3") using the trigger on the gun.
- Adjust the flow control knob on the back of the gun to determine how far back the trigger can be pulled, thus setting the bead to a desired diameter.

2. REPLACING A CAN OF FOAM

- Do not replace until can is empty.
- Tighten the flow control knob.
- Unscrew empty can.
- Place a can of cleaner on the gun and tighten down. (**DO NOT PULL THE TRIGGER**—pressure allows enough cleaner in to keep the ball valve clean.) Remove the cleaner.
- Screw on a new can of foam immediately—do not leave gun without a can of foam or cleaner attached. (Exposure to air will cause foam in the gun to cure.)

3. CLEANING THE GUN

- Install a can of foam cleaner to the gun, and spray until all foam is blown out of gun and only cleaner is visible (approximately 1/2 can of cleaner). **DO NOT** leave cleaner can on gun for more than 15 minutes maximum.
- Install new can of foam and dispense foam for 15 seconds, or until all cleaner is purged from foam gun.

*** Remember: Leave can on gun at all times, remove only to replace or clean.**